

Budda Amplification – Phatman Distortion Pedal

CHANGING TUBES

Through the course of time, preamp tubes may lose their power and, or become microphonic. If you notice that your pedal may be losing gain and output, or there is a crackling or noise from the unit, replace the preamp tubes to assure maximum performance.

Changing pre amp tubes is an easy task and is accomplished by the following procedure.

- 1. Loosen thumb screws on both sides of the tube cover plate. They are numbered #1 and 2 above.**
- 2. Pull plate off to expose tubes. Wait for the tubes to cool before attempting to pull them out of their sockets.**
- 3. Align the pins on new tube with tube socket holes on the circuit board and gently push in until they are firmly in place.**
- 4. Attach cover plate and let er' rip!**

! CAUTION !

RISK OF ELECTROCUTION

Do not open!

There are no user serviceable parts inside this unit!

Refer to Budda Amplification or qualified service shop for repairs!

**Budda Amplification
37 Joseph Court
San Rafael, CA 94903
Ph 415-492-1935
Fax 415-492-1663
e mail buddatone@budda.com**