



Budda Amplification Superdrive 18 Tube Chart




Budda Amplification Superdrive 30 Tube Chart



Budda Amplification Superdrive 80 Tube Chart



Budda Amplification Superdrive 45 Tube Chart



Your power tubes may need replacing if:

1. There is a Reduction in volume
2. They are glowing a bright red
3. There is an intermittent crackling noise when plugging guitar into effects return jack.
4. There is a loss of high end definition

Your preamp tubes may need replacing if:

1. There is a microphonic squeal or whistling when amp is turned on
2. There is an intermittent crackling sound when guitar is plugged into input
3. There is a loss of gain

Your rectifier tube may need replacing if:

1. Your amplifier power tubes are not receiving power. Check fuse first.

Budda recommends that you change your power tubes every 6 months to assure optimum performance from your amplifier. We offer quality replacements through authorized Budda retail stores, check our website for a dealer location near you.