



### Budda Amplification Superdrive 18 Tube Chart




### Budda Amplification Superdrive 30 Tube Chart



### Budda Amplification Superdrive 80 Tube Chart



## Budda Amplification Superdrive 45 Tube Chart



Your power tubes may need replacing if:

1. There is a Reduction in volume
2. They are glowing a bright red
3. There is an intermittent crackling noise when plugging guitar into effects return jack.
4. There is a loss of high end definition

Your preamp tubes may need replacing if:

1. There is a microphonic squeal or whistling when amp is turned on
2. There is an intermittent crackling sound when guitar is plugged into input
3. There is a loss of gain

Your rectifier tube may need replacing if:

1. Your amplifier power tubes are not receiving power. Check fuse first.

Budda recommends that you change your power tubes every 6 months to assure optimum performance from your amplifier. We offer quality replacements through authorized Budda retail stores, check our website for a dealer location near you.